
Nikon Rayfact

Tochigi Nikon Industrial Lens

TOCHIGI NIKON CORPORATION

Marketing Sec. Industrial Equipment Dept.



2-5x Lens

- NikonRavfact2-5x
- NikonRayfact2-5x (prism suitable model)

Nikon Rayfact Series

- NikonRayfact7x(Straight-tube type)
- NikonRayfact7x (Coaxial epi-illumination type)
- NikonRavfact3.5x
- NikonRayfact2.35x(Build-to-order product)
- NikonRayfact2x
- NikonRayfact1.75x(Build-to-order product)
- NikonRayfact1x

Nikon Rayfact VL Series

- NikonRayfactVL0.5x
- NikonRayfactVL0.7x
- NikonRayfactVL1.0x
- NikonRayfactVL1.4x

Nikon Rayfact VW Series

- NikonRayfactVW0.14x
- NikonRayfactVW0.25x
- NikonRayfactVW0.35x

Nikon Rayfact MJ Series

- NikonRayfactMJ90mmF4
- NikonRayfactMJ95mmF4

Nikon Rayfact VF

- NikonRavfactVF
- NikonRayfactVF1.0x
- NikonRayfactVF1.4x
- NikonRayfactVF2.0x
- NikonRayfactVF2.5x
- NikonRayfactVF3.0x

Nikon Rayfact GF Series

- NikonRayfact80mmF4 0.235x
 - (Build-to-order product)
- NikonRayfact80mmF4 0.47x (Build-to-order product)
- NikonRayfact80mmF4 0.7x
- (Build-to-order product) NikonRayfact80mmF4 1.0x
- (Build-to-order product)

Nikon Rayfact IL Series

- NikonRayfactIL40mm (Build-to-order product)
- NikonRayfactIL50mmF2.8N
- NikonRayfactIL63mmF2.8N
- NikonRayfactIL75mmF4N
- NikonRayfactIL95mmF5.6N
- NikonRayfactIL63mmF2.8N(F)

UV105mm-F4.5

UV105mm-F4.5

2-5x Variable Lens

Features

- Variable magnification: 2 5x
- Prism optical optimization model available. (Coaxial vertical prism: Thickness up to 25mm)
 (Coaxial vertical prism not available at Tochigi Nikon)
- Large image size ϕ 84mm For high resolution, large-sized line sensor cameras.
- Recommendable line sensor cameras 5 μ m x 16K / 5.2 μ m x 12K / 7 μ m x 8K
- Less difference in performance, securing performance in the whole range of magnification.
- · Variable diaphragm, open aperture F2.5
- · Diaphragm and floating ring setting lockable screws
- Gear on the diaphragm ring and the floating ring to have the mechanism be variable by external driving.
- · RoHs compliant

- · Inspection by high-resolution line censor cameras
- · Flat panel inspection
- · PCB inspection
- · Wafer inspection

NikonRayfact2-5x Variable Lens



Specifications

opecineations								
Model		L-OVM50167MN						
Magnification range		$-2.0x\sim-5.0x$						
Magnification	-2.0x	-2.5x	-3.0x	-3.5x	-4.0x	-4.5x	-5.0x	(-5.2x)%2
Focal length				116	mm			
F Number (∞)				F2	2.5			
NA (Diaphragm open)	0.133	0.143	0.15	0.156	0.16	0.164	0.167	0.168
Reference wavelength				546.07nr	n (e-line)			
Wavelength range				400~	700nm			
Image size	φ 84mm							
Object size 💥1	ϕ 42mm	ϕ 33.6mm	φ 28mm	φ 24mm	φ 21mm	φ 18.7mm	φ 16.8mm	(φ16.2mm)
Distortion ※1	+0.08%	+0.01%	-0.02%	-0.03%	-0.03%	-0.03%	-0.03%	(-0.03%)
Relative illumination ※1	91.2%	95.7%	98.1%	98.9%	99.1%	99.1%	99.2%	(99.2%)
Aperture scale				2.5,2.8,4	,5.6,8,11			
Object-to-image distance	503.6mm	550.4mm	601.0mm	653.8mm	707.9mm	763.0mm	818.7mm	(841.1mm)
Working distance	114.7mm	102.8mm	94.9mm	89.2mm	84.9mm	81.6mm	79.0mm	(78.1mm)
Mount size	M67(P=0.75)							
Flange-to image distance	248.8mm	307.5mm	366.1mm	424.6mm	483.0mm	541.4mm	599.8mm	(623.1mm)
Attachment size	M58 (P=0.75)							
Diameter/length	φ 84mm×140mm							
Weight				Approxima	tely 1350g			


^{※1} Highest image height (Y'=42mm) at F2.5.

² -5.2x:To fix the magnification at -5.0x and move the lens outward up to the maximal point.

				-2.0x	-2.5x	-3.0x	-3.5x	-4.0x	-4.5x	-5.0x	(-5.2x)
Entrance	d		[En.P]	60.75mm	(60.75mm)						
pupil ※ 3	φ			φ 47.2mm	ϕ 47.2mm	ϕ 47.3mm	φ 47.4mm	φ 47.4mm	φ 47.4mm	φ 47.4mm	(ϕ 47.4mm)
Exit pupil	d		[Ex.P]	98.57mm	98.55mm	98.52mm	98.49mm	98.46mm	98.43mm	98.41mm	(98.41mm)
※ 3	φ			ϕ 46.4mm	ϕ 46.5mm	ϕ 46.6mm	ϕ 46.7mm	ϕ 46.8mm	ϕ 46.8mm	ϕ 46.9mm	(ϕ 46.9mm)
Front Principal	Point	※ 3	[Front.PP]	59.57mm	59.92mm	60.17mm	60.36mm	60.49mm	60.62mm	60.71mm	(60.71mm)
Rear Principal l	Point	₩3	[Rear.PP]	99.74mm	99.37mm	99.10mm	98.88mm	98.72mm	98.57mm	98.45mm	(98.45mm)
Nodal Point	Dista	nce	[HH']	-19.3mm	-19.29mm	-19.27mm	-19.24mm	-19.21mm	-19.19mm	-19.16mm	(-19.16mm)

3 Entrance pupil En.P and principal point H at the front tip point of the lens.

Exit pupil(Ex.P), Rear Principal Point(H') : at the mount point. Image side: $\lceil + \rfloor$ Object side: $\lceil - \rfloor$



- •Specifications unless any specific instructions are stated is at the standard magnification.
- Specifications are subject to change without prior notice.

NikonRayfact2-5x Variable Lens: Prism suitable model



Specifications

Specifications								
Model		L-OVM50170MN-BS						
Magnification range		$-2.0x\sim-5.0x$						
Magnification	-2.0x	-2.5x	-3.0x	-3.5x	-4.0x	-4.5x	-5.0x	(-5.2x)%2
Focal length				117	mm			
F Number (∞)				F2	2.5			
NA (Diaphragm open)	0.133	0.144	0.151	0.157	0.162	0.166	0.17	0.171
Reference wavelength				546.07nı	m(e-line)			
Wavelength range				400~	700nm			
Image size	φ 84mm							
Object size 💥1	φ 42mm	ϕ 33.6mm	φ 28mm	φ 24mm	φ 21mm	φ 18.7mm	φ 16.8mm	$(\phi 16.2 \text{mm})$
Distortion ※1	+0.06%	-0.01%	-0.03%	-0.04%	-0.05%	-0.04%	-0.04%	(-0.04%)
Relative illumination ※1	88.9%	93.6%	96.2%	97.3%	97.9%	98.3%	98.7%	(98.8%)
Aperture scale				2.5,2.8,4	,5.6,8,11			
Object-to-image distance	513.7mm	561mm	612.1mm	665.4mm	720.1mm	775.7mm	831.9mm	(854.5 mm)
Working distance	119.8mm	107.8mm	99.8mm	94mm	89.7mm	86.35mm	83.7mm	(82.8mm)
Mount size	M67(P=0.75)							
Flange-to image distance	253.9mm	313.2mm	372.3mm	431.4mm	490.3mm	549.3mm	608.3mm	(631.8 mm)
Attachment size	M58 (P=0.75)							
Diameter/length	φ84mm×140mm							
Weight		•	•	Approxima	tely 1350g	•	•	•


*1 Highest image height (Y'=42mm) at F2.5 with prism (25mm thickness material BK7 or equivalent) to put between an object and the lens.

² -5.2x:To fix the magnification at -5.0x and move the lens outward up to the maximal point.

				0.0	0.5	0.0	0.5	4.0	4.5	Γ.0	(5 0)
				-2.0x	-2.5x	-3.0x	-3.5x	-4.0x	−4.5x	-5.0x	(-5.2x)
Entrance	d		[En.P]	58.57mm	(58.57mm)						
pupil ※ 3	φ			ϕ 45.7mm	ϕ 45.8mm	ϕ 45.9mm	ϕ 45.9mm	ϕ 46.0mm	ϕ 46.0mm	ϕ 46.0mm	(ϕ 46.0mm)
Exit pupil	d		[Ex.P]	104.62mm	104.63mm	104.62mm	104.60mm	104.58mm	104.56mm	104.54mm	(104.54mm)
※ 3	φ			ϕ 48.0mm	φ 48.1mm	ϕ 48.2mm	φ 48.3mm	ϕ 48.4mm	ϕ 48.4mm	ϕ 48.5mm	(ϕ 48.5mm)
Front Principal	Point	※ 3	[Front.PP]	64.76mm	65.11mm	65.35mm	65.54mm	65.66mm	65.79mm	65.88mm	(65.88mm)
Rear Principal I	Point	※ 3	[Rear.PP]	98.09mm	97.70mm	97.42mm	97.19mm	97.03mm	96.87mm	96.75mm	(96.75mm)
Nodal Point I	Dista	ince	[HH']	-22.9mm	-22.8mm	-22.8mm	-22.7mm	-22.7mm	-22.7mm	-22.6mm	-22.6mm

3 Entrance pupil En.P and principal point H at the front tip point of the lens.

 $\text{Exit pupil}(\text{Ex.P}), \, \text{Rear Principal Point}(\text{H}'): \text{at the mount point. Image side: $$\lceil + \rfloor$} \quad \text{Object side: $$\lceil - \rfloor$}$



- •Specifications unless any specific instructions are stated is at the standard magnification.
- Specifications are subject to change without prior notice.

For further queries, please contact;
Marketing Sec. Industrial Equipment Dept.
TOCHIGI NIKON CORPORATION
E-mail:ktn.eigyo@nikon.com
TEL+81-287-28-7100 FAX+81-287-28-7170

Nikon Rayfact Series

Features

- Rayfact 2x and 1x: successor models to Printing Nikkor Lenses.
- No lens aberration (0.0%) at the standard magnification ratio.
- Guarantee high resolution and uniformity from the center to the edge of the lens.
- Anti-reflection coating applied to minimize lens surface reflection.
- Rayfact 2x and 1x: Apochromatic lens with the best chromatic aberration correction in the wide-range of 400-800nm.
- Rayfact 7x and 3.5x : Image size $\,\phi\,64\text{mm}$ has a high relative illumination.
- Rayfact 7x : Bilateral telecentric lenses.
- · RoHS compliant.

- Inspection by high resolution line sensor cameras.
- FPD inspection.
- Fine pattern inspection e.g. PCB.
- Printed materials inspection.
- Reproduction of color and monochrome film in the same size or scaling and data fetch.
- 35mm format : Enlargement of half format sliding and reduction copy.







Model	OFM70350HN-TS		
Focal length	Both sides telecentric		
NA	0.35		
Magnification scale	−7.0x		
Reference wavelength	546.07nm(e-line)		
Wavelength range	510∼590nm		
Picture angle	_		
Image size	64mm ϕ		
Object size	9.1mm ϕ		
Distortion	0.0%(at 64mm ϕ)		
Relative illumination	103% (at 64mm ϕ)		
Aperture scale	A fixed diaphragm		
Object-to-image distance	613.9mm		
Working distance	54.8mm		
Mount size	M72(P=0.75)		
Flange-to-image distance	19.55mm		
Back focus	81.17mm		
Attachment size	M96(P=1.0)		
Diameter/length	145mm $\phi \times 544.5$ mm		
Weight	Approximately 7.4kg		
An option	-		

Model	OFM70350HN-TP			
Focal length	Both sides telecentric			
NA	0.35			
Magnification scale	-7.0x			
Reference wavelength	546.07nm(e-line)			
Wavelength range	510∼590nm			
Picture angle	_			
Image size	64mm ϕ			
Object size	9.1 mm ϕ			
Distortion	0.0%(64mm)			
Relative illumination	103% (64mm)			
Aperture scale	Fixed diaphragm			
Object-to-image distance	624.5mm			
Working distance	54.8mm			
Mount size	M72(P=0.75)			
Flange-to-image distance	19.55mm			
Back focus	58.75mm			
Attachment size	M96(P=1.0)			
Diameter/length	145mm ϕ (partially \square 119.5mm) \times 555.1mm			
Weight	Approximately 8.9kg			
An option	_			
X Suitable for line concer	00700700			

X Suitable for line sensor cameras.





 $^{{}^{}ullet}$ Specifications unless any specific instructions are stated is at the standard magnification.

[•]Specifications are subject to change without prior notice.






Opecifications				
Model	OFM35162MN			
Focal length	127.0mm			
F Number (∞)	F2.4			
NA (Diaphragm open)	0.162			
Magnification scale	−3.5x			
Reference wavelength	546.07nm(e-line)			
Wavelength range	400∼700nm			
Picture angle	5.7°			
Image size	64mm ϕ			
Object size	18.3mm ϕ			
Distortion	0.0% (at 64 mm ϕ)			
Relative illumination	98%(at 64mm ϕ)			
Aperture scale	2.4,4,5.6,8,11 (9° interval %1, 1/2 dials with a finger stop) %2			
Object-to-image distance	651.3mm			
Working distance	70.8mm			
Mount size	M67(P=0.75)			
Flange-to-image distance	505.0mm			
Back focus	437.9mm			
Attachment size	M46(P=0.75)			
Diameter/length	73mm φ × 145.7mm ※3			
Weight	Approximately 1.1kg			
Option	Coaxial vertical tube			

Model	OFM24125MN				
Focal length	95.1mm				
F Number (∞)	F2.8				
NA (Diaphragm open)	0.125				
Magnification scale	−2.35x				
Reference wavelength	546.07nm(e-line)				
Wavelength range	400∼800nm				
Picture angle	11.4°				
Image size	64mm ϕ				
Object size	27.24mm ϕ				
Distortion	0.0%(at 64mm ϕ)				
Relative illumination	78.9%(at 64mm ϕ)				
Aperture scale	2.8,4,5.6,8,11 (18° interval, 1/2 dials with a finger stop)				
Object-to-image distance	424.2mm				
Working distance	79.5mm				
Mount size	M45(P=0.75)				
Flange-to-image distance	254.5mm				
Back focus	255.4mm				
Attachment size	_				
Diameter/length	57 mm $\phi \times 94.2$ mm				
Weight	Approximately 420g				

- ※1 Aperture scale at 2.8: Only lock-in position available. No numeric indication.
- $\frak{\%}2$ Lockable setting mechanism.
- 3 Dimension excludes protrusion of screws or other convex part.




- •Specifications unless any specific instructions are stated is at the standard magnification.
- •Specifications are subject to change without prior notice.





Opcomoadons						
Mandal	OFM20119MN					
Model	In use −2.0x	In use −0.5x				
Focal length	95.0mm					
F Number (∞)	F2	2.8				
NA (Diaphragm open)	8.4 (at Standard magnification)	4.2 (at Standard magnification)				
Magnification scale	-2.0x	−0.5x				
Reference wavelength	546.07nn	n(e-line)				
Wavelength range	400~8	800nm				
Picture angle	12.8°	12.8°				
Image size	64mm ϕ	32mm ϕ				
Object size	32mm ϕ	64mm ϕ				
Distortion	0.0% (at 64 mm ϕ)	0.0% (at 32 mm ϕ)				
Relative illumination	74.6% (64mm ϕ)	74.6% (32mm ϕ)				
Aperture scale	2.8,4,5.6,8,11 (18° interval, 1/2 dials with a finger stop)					
Object-to-image distance	397.6mm					
Working distance	87.0mm	212.4mm				
Mount size	M45(P	=0.75)				
Flange-to-image distance	220.4mm	124.9mm				
Back focus	222.0mm	90.3mm				
Attachment size	_	M43(P=0.5)				
Diameter/length	57 mm $\phi \times 98.2$ mm					
Weight	Approximately 420g					

Model	L-OFM18113MN				
Focal length	100.2mm				
F Number (∞)	F2.8				
NA (Diaphragm open)	0.113				
Magnification scale	−1.75x				
Reference wavelength	546.07nm(e-line)				
Wavelength range	400∼800nm				
Picture angle	17.8°				
Image size	64mm ϕ				
Object size	36.57mm ϕ				
Distortion	0.1%(at 64mm ϕ)				
Relative illumination	65.2%(at 64mm ϕ)				
A	2.8,4,5.6,8,11				
Aperture scale	$(18^{\circ}$ interval, $1/2$ dials with a finger stop)				
Object-to-image distance	392.1mm				
Working distance	92.6mm				
Mount size	M45(P=0.75)				
Flange-to-image distance	203.2mm				
Back focus	200.4mm				
Attachment size	_				
Diameter/length	57 mm $\phi \times 100.3$ mm				
Weight	Approximately 430g				




[•] Specifications unless any specific instructions are stated is at the standard magnification.

 $[\]mbox{-}\!\operatorname{Specifications}$ are subject to change without prior notice.



OFM10090MN			
104.5mm			
F2.8			
0.089			
−1.0x			
546.07nm(e-line)			
400∼800nm			
16.3°			
60mm ϕ			
60mm ϕ			
0.0%(at 60mm ϕ)			
62%(at 60mm ϕ)			
2.8,4,5.6,8,11			
$(18^{\circ}$ interval, $1/2$ dials with a finger stop)			
388.1mm			
140.1mm			
M45(P=0.75)			
189.8mm			
147.7mm			
M43(P=0.5)			
57 mm $\phi \times 107.3$ mm			
Approximately 400g			



[•]Specifications unless any specific instructions are stated is at the standard magnification.

[•]Specifications are subject to change without prior notice.

For further queries, please contact;
Marketing Sec. Industrial Equipment Dept.
TOCHIGI NIKON CORPORATION
F-mail: ktn eigro@nikon.com

E-mail: ktn.eigyo@nikon.com TEL+81-287-28-7100 FAX+81-287-28-7170

Nikon Rayfact VL Series

Features

- The optimal design for line censor cameras of 7 μ m x 8K / 5 μ m x 12K.
- Large image size ϕ 62mm suitable for high resolution cameras.
- Wide range of magnification at 0.5x, 0.7x, 1.0x and 1.4x for various applications.
- Minimal distortion (0.0% at the standard magnification).
- High resolution and uniformity from the center to the edge of the lens.
- Best performance at a diaphragm opening position.
- Rotating mount mechanism enables you to align the lens at the best resolution direction.
- · Lockable screws to fix an aperture required.
- RoHS compliant.

- · Inspection by high resolution line sensor cameras.
- FPD inspection.
- Fine pattern inspection e.g. PCB.
- Printed materials inspection.
- Fine pattern inspection and detecting defects e.g. TAB, sheets.

NikonRavfactVL0.7x






Specifications


L-OFM05034MN			
122.0mm			
F4.9			
0.034			
−0.5x			
546.07nm(e-line)			
400∼700nm			
19.4°			
62mm ϕ			
124.0mm ϕ			
0.0% ※1			
92.9% ※1			
4.9, 5.6, 8, 11 (With a click stop, short lines are 1/2 aperture) $%2$			
531.9mm			
275.3mm			
M55(P=0.75)			
156.2mm			
124.4mm			
M55(P=0.75)			
73.5mm $\phi \times 134.9$ mm $\%3$			
Approximately 820g			

- %1 Image size 62mm ϕ at F4.9.
- $\divideontimes 2$ Diaphragm scale indicated with indexes. No numeric indication.
- 3 Dimension excludes protrusion of screws or other convex part.

Model	L-OFM07042MN
Focal length	122.0mm
F Number (∞)	F4.9
NA (Diaphragm open)	0.042
Magnification scale	−0.7x
Reference wavelength	546.07nm(e-line)
Wavelength range	400∼700nm
Picture angle	17.1°
Image size	62mm ϕ
Object Size	88.6mm ϕ
Distortion	0.0% ※1
Relative illumination	94.3% ※1
Aperture scale	4.9, 5.6, 8, 11 (With a click stop, short lines are 1/2 aperture) $%2$
Object-to-image distance	486.4mm
Working distance	216.1mm
Mount size	M55(P=0.75)
Flange-to-image distance	180.3mm
Back focus	135.2mm
Attachment size	M55(P=0.75)
Diameter/length	73.5mm ϕ × 137.8mm $\%$ 3
Weight	Approximately 780g

- 31 Image size 62mm ϕ at F4.9.
- $\divideontimes 2$ Diaphragm scale indicated with indexes. No numeric indication.
- 3 Dimension excludes protrusion of screws or other convex part.





[•]Specifications unless any specific instructions are stated is at the standard magnification.

 $^{{}^{\}scriptscriptstyle \bullet}\mathsf{Specifications}$ are subject to change without prior notice.

NikonRayfactVL1.4x






Specifications


L-OFM10051MN
122.0mm
F4.9
0.051
−1.0x
546.07nm(e-line)
400∼700nm
14.5°
62mm ϕ
φ62.0mm
0.0% ※1
95.6% ※1
$4.9, 5.6, 8, 11$ (With a click stop, short lines are 1/2 aperture) $\mbox{\%}2$
470.9mm
177.8mm
M55(P=0.75)
216.5mm
152.5mm
M55(P=0.75)
73.5mm ϕ × 143.3mm $\%$ 3
Approximately 840g

- 31 Image size 62mm ϕ at F4.9.
- $\divideontimes 2$ Diaphragm scale indicated with indexes. No numeric indication.
- 3 Dimension excludes protrusion of screws or other convex part.

Model	L-OFM14060MN
Focal length	122.0mm
F Number (∞)	F4.9
NA (Diaphragm open)	0.06
Magnification scale	−1.4x
Reference wavelength	546.07nm(e-line)
Wavelength range	400∼700nm
Picture angle	12.0°
Image size	62mm ϕ
Object Size	ϕ 44.3mm
Distortion	0.0% ※1
Relative illumination	96.8% ※1
Aperture scale	4.9,5.6,8,11
Aperture scale	(With a click stop, short lines are $1/2$ aperture) $ ilde{ imes}2$
Object-to-image distance	484.6mm
Working distance	130.0mm
Mount size	M55(P=0.75)
Flange-to-image distance	205.6mm
Back focus	220.6mm
Attachment size	M55(P=0.75)
Diameter/length	73.5mm ϕ × 154mm $\%$ 3
Weight	Approximately 920g

- %1 Image size 62mm ϕ at F4.9.
- $\frak{\%}2$ Diaphragm scale indicated with indexes. No numeric indication.
- 3 Dimension excludes protrusion of screws or other convex part.





[•]Specifications unless any specific instructions are stated is at the standard magnification.

[•]Specifications are subject to change without prior notice.

For further queries, please contact;
Marketing Sec. Industrial Equipment Dept.
TOCHIGI NIKON CORPORATION
E-mail:ktn.eigyo@nikon.com
TEL+81-287-28-7100 FAX+81-287-28-7170

207 20 7100 1 740 207 20 7170

Features

- Low magnification line-up suitable for large-sized line sensor cameras.
- Image size φ 62mm to meet your use of large-sized high resolution line censor cameras.
- Optical design suitable for line censor cameras : $7~\mu$ m x 8K / $5~\mu$ m x 12K. Also, avaulable for $3.5~\mu$ m x 16K line sensor cameras.
- 3 models at the magnification range (0.1x 0.4x) for your best choice.
- High resolution and uniformity from the center to the edge of the lens.
- Best performance at a diaphragm opening position.
- Minimal distortion (below 0.1% at the standard magnification).
- · Rotating mount mechanism enables you to align the lens at the best resolution direction.
- · Lockable screws to fix an aperture required.
- · RoHS compliant.

- Suitable for high resolution cameras (CCD pixel size : 7μ m / 5μ m)
- FPD inspection.
- Fine pattern inspection e.g. PCB.
- Printed materials inspection.
- Fine pattern inspection and detecting defects e.g. TAB, sheets.

NikonRayfactVW0.25x






Specifications


L-OFM014012MN
125.5mm
F4.9
0.013
−0.14x
-0.1x ~ -0.18x
546.07nm(e-line)
400∼700nm
24.7° ※1
62mm ϕ
442.9mm <i>φ</i>
0.0% ※1
90.9% ※1
4.9,5.6,8,11 (With a click stop) ※2
1144.6mm ※1
960.2mm ※1
M55(P=0.75)
120.0mm ※1
87.9mm
M55(P=0.75)
73.5mm $\phi \times 98.7$ mm $\%$ 3
Approximately 740g

- ★1 Value at the standard magnification.
- $\divideontimes 2$ Diaphragm scale indicated with indexes. No numeric indication.
- 3 Dimension excludes protrusion of screws or other convex part.

Model	L-OFM025020MN
Focal length	124.9mm
F Number (∞)	F4.9
NA (Diaphragm open)	0.02
Magnification scale	−0.25x
Magnification range	-0.18x ~ -0.28x
Reference wavelength	546.07nm(e-line)
Wavelength range	400∼700nm
Picture angle	22.9° ※1
Image size	62mm ϕ
Object Size	248.0mm ϕ $\%$ 1
Distortion	−0.1% ※ 1
Relative illumination	93.4% ※1
Aperture scale	4.9,5.6,8,11 (With a click stop) ※2
Object-to-image distance	761.1mm ※1
Working distance	562.9mm ※1
Mount size	M55(P=0.75)
Flange-to-image distance	133.9mm ※1
Back focus	102.7mm
Attachment size	M55(P=0.75)
Diameter/length	73.5mm ϕ × 97.7mm \times 3
Weight	Approximately 740g

- X1 Value at the standard magnification.
- ※2 Diaphragm scale indicated with indexes. No numeric indication.
- 3 Dimension excludes protrusion of screws or other convex part.






- •Specifications unless any specific instructions are stated is at the standard magnification.
- •Specifications are subject to change without prior notice.



Model	L-OFM035026MN
Focal length	125.2mm
F Number (∞)	F4.9
NA (Diaphragm open)	0.026
Magnification scale	−0.35x
Magnification range	-0.28x ~ -0.4x
Reference wavelength	546.07nm(e-line)
Wavelength range	400∼700nm
Picture angle	21.3° ※1
Image size	62mm ϕ
Object Size	177.1mm <i>ф</i> ※ 1
Distortion	−0.1% ※ 1
Relative illumination	94.3% ※1
Aperture scale	4.9,5.6,8,11 (With a click stop) ※2
Object-to-image distance	631.7mm ※1
Working distance	419.8mm ※1
Mount size	M55(P=0.75)
Flange-to-image distance	147.5mm ※1
Back focus	115.6mm
Attachment size	M55(P=0.75)
Diameter/length	73.5mm ϕ × 97.7mm $\%$ 3
Weight	Approximately 740g

- X1 Value at the standard magnification.
- ※2 Diaphragm scale indicated with indexes. No numeric indication.
- $\frak{\%}3$ Dimension excludes protrusion of screws or other convex part.



[•]Specifications unless any specific instructions are stated is at the standard magnification.

[•] Specifications are subject to change without prior notice.

For further queries, please contact;
Marketing Sec. Industrial Equipment Dept.
TOCHIGI NIKON CORPORATION
E-mail:ktn.eigyo@nikon.com
TEL+81-287-28-7100 FAX+81-287-28-7170

Nikon Rayfact VF


Features

- Variable magnification range: 0.5x 3.0x
- Image size ϕ 64mm to meet large-sized high resolution line censor cameras.
- Suitable for line censor cameras of 7 μ m x 8K / 5 μ m x 12K.
- \bullet High performance guaranteed in all range of magnification.
- · Adjustable diaphragm, Diaphragm open position at F4.
- Aperture lockable screw and floating ring lockable screw for easy use.
- Rotating mount mechanism enables you to align the lens at the best resolution direction.
- Fixed magnification model: Choice of 5 types of magnification (1.0x 1.4x 2.0x 2.5x 3.0x)
- Fixed magnification model: 3 types (Magnification at 2.0x 2.5x 3.0x) secure image size of φ84mm.
- RoHS compliant.

- Image receiving process by both line and area censor cameras.
- Printed materials inspection.
- Fine pattern inspection e.g. PCB.
- Fine pattern inspection and detecting defects e.g. TAB, sheets.
- · FPD inspection.

NikonRayfactVF





opecifications					/ = =	(0)	-la (V/
Model		L-OVM30093MN					
Magnification range			-	-0.5x ~ −3.0	×		
Magnification scale	−0.5x	−0.7x	−1.0x	−1.4x	-2.0x	−2.5x	−3.0x
Focal length				90mm			
F Number (∞)				F4			
NA (Diaphragm open)	0.042	0.051	0.062	0.073	0.083	0.089	0.093
Reference wavelength			54	6.07nm(e-lii	ne)		
Wavelength range				400∼700nn	ı		
Image size		64mm ϕ					
Object Size	128.0mm ϕ	91.4mm ϕ	64.0 mm ϕ	45.7mm ϕ	32.0 mm ϕ	25.6 mm ϕ	21.3mm ϕ
Distortion ※1	+0.18%	+0.07%	+0.00%	-0.03%	-0.04%	-0.04%	-0.04%
Relative illumination ※1	56%	67%	78%	87%	93%	94%	95%
Aperture scale		4,5.6,8 (With a diaphragm lock)					
Object-to-image distance	405.93mm	371.87mm	360.08mm	370.56mm	405.93mm	442.62mm	482.36mm
Working distance	239.66mm	187.16mm	147.74mm	121.42mm	101.67mm	92.44mm	86.29mm
Mount size		M45(P=0.75)					
Flange-to-image distance	98.77mm	117.21mm	144.84mm	181.64mm	236.77mm	282.68mm	328.57mm
Attachment size		M49(P=0.75)					
Diameter/length		58mm ∅ × 67.5mm					
Weight		Approximately 430g					

^{※1} Highest image height (Y'=32mm) at F4.

		−0.5x	−0.7x	−1.0x	−1.4x	-2.0x	−2.5x	−3.0x
Entrance Pupil		34.32mm	34.93mm	35.69mm	36.44mm	37.12mm	37.48mm	37.75mm
		22.8mm	22.9mm	23.0mm	23.0mm	23.1mm	23.2mm	23.2mm
Exit Pupil	d	39.97mm	39.34mm	38.59mm	37.83mm	37.18mm	36.82mm	35.56mm
Exit Pupil	φ	23.1mm	23.0mm	23.0mm	22.8mm	22.7mm	22.7mm	22.7mm
Front Principal Point		35.48mm	35.57mm	35.69mm	35.80mm	35.90mm	35.96mm	36.00mm
Rear Principal Point		38.79mm	38.7mm	38.59mm	38.47mm	38.37mm	38.32mm	38.28mm
Nodal point distance		−6.77mm	−6.77mm	−6.78mm	-6.77mm	−6.77mm	-6.78mm	−6.78mm

β	(A)	(B)	(C)	(D)	(E)	(F)	(G)	(J)
-0.5	239.66		98.77	405.93	$34.32(\phi 22.8)$	$39.97(\phi 23.1)$	35.48	38.79
-0.7	187.16		117.21	371.87	$34.93(\phi 22.9)$	39.34(<i>ф</i> 23.0)	35.57	38.70
-1.0	147.74		144.84	360.08	$35.69(\phi 23.0)$	$38.59(\phi 23.0)$	35.69	38.59
-1.4	121.42	67.5	181.64	370.56	36.44(ϕ 23.0)	$37.83(\phi 22.8)$	35.80	38.47
-2.0	101.66		236.77	405.93	$37.12(\phi 23.1)$	$37.18(\phi 22.7)$	35.90	38.37
-2.5	92.44		282.68	442.62	$37.48(\phi 23.2)$	$36.82(\phi 22.7)$	35.96	38.32
-3.0	86.29		328.57	482.36	$37.75(\phi 23.2)$	35.56(<i>ф</i> 22.7)	36.00	38.28

[•]Specifications unless any specific instructions are stated is at the standard magnification.

[•] Specifications are subject to change without prior notice.

NikonRayfactVF 1.0x



Specifications

L-OFM10062MN
91.7mm
F4
0.062
-1.0x
546.07nm(e-line)
400∼700nm
19.8°
64mm ϕ
64mm ϕ
0% ※1
77.9% ※1
4,5.6,8 (With a click stop ※2)
360.1mm
147.2mm
M45(P=0.75)
153.6mm
154.9mm
M40.5(P=0.5)
51mm <i>φ</i> × 59.2mm ※ 3
Approximately 240g

- %1 Image size 64mm ϕ at F4
- X2 Diaphragm scale indicated with indexes.

No numeric indication. The open position index states as "O".

3 Dimension excludes protrusion of screws or other convex part.

NikonRayfactVF 1.4x




Specifications


Model	L-OFM14073MN
Focal length	91.7mm
F Number (∞)	F4
NA (Diaphragm open)	0.073
Magnification scale	−1.4x
Reference wavelength	546.07nm(e-line)
Wavelength range	400∼700nm
Picture angle	16.4°
Image size	64mm ϕ
Object Size	45.7mm ϕ
Distortion	−0.03% ※ 1
Relative illumination	87.4% ※1
Aperture scale	4,5.6,8(With a click stop ※2)
Object-to-image distance	370.5mm
Working distance	121.3mm
Mount size	M45(P=0.75)
Flange-to-image distance	190mm
Back focus	191.7mm
Attachment size	M40.5(P=0.5)
Diameter/length	$51 \text{mm} \phi \times 59.2 \text{mm} \%3$
Weight	Approximately 240g
V/4 1 1 04 1	. = 4

- \divideontimes 1 Image size 64mm ϕ at F4
- ※2 Diaphragm scale indicated with indexes.

No numeric indication. The open position index states as "O'

3 Dimension excludes protrusion of screws or other convex part.





[•]Specifications unless any specific instructions are stated is at the standard magnification.

[•]Specifications are subject to change without prior notice.

NikonRayfactVF 2.0x



Specifications

L-OFM20083MN
91.6mm
F4
0.083
−2.0x
546.07nm(e-line)
400∼700nm
17.2°
84mm ϕ
42.0mm ϕ
−0.07% ※ 1
85.5% ※1
4,5.6,8 (With a click stop ※2)
405.6mm
101.9mm
M45(P=0.75)
244.5mm
246.7mm
M40.5(P=0.5)
51mm <i>φ</i> × 59.2mm ※3
Approximately 240g


- %1 Image size 84mm ϕ at F4
- X2 Diaphragm scale indicated with indexes.
 - No numeric indication. The open position index states as "O".
- $\divideontimes 3$ Dimension excludes protrusion of screws or other convex part.


NikonRayfactVF 2.5x



Model	L-OFM25089MN
Focal length	91.6mm
F Number (∞)	F4
NA (Diaphragm open)	0.089
Magnification scale	−2.5x
Reference wavelength	546.07nm(e-line)
Wavelength range	400~700nm
Picture angle	14.8°
Image size	84mm ϕ
Object Size	33.6mm ϕ
Distortion	−0.07% ※ 1
Relative illumination	90.0% ※1
Aperture scale	4,5.6,8 (With a click stop ※2)
Object-to-image distance	442.2mm
Working distance	92.9mm
Mount size	M45(P=0.75)
Flange-to-image distance	290.1mm
Back focus	292.6mm
Attachment size	M40.5(P=0.5)
Diameter/length	51mm φ × 59.2mm ※3
Weight	Approximately 240g
V1 I	. = 4

- imes1 Image size 84mm ϕ at F4
- ※2 Diaphragm scale indicated with indexes.
 - No numeric indication. The open position index states as $^{''}\text{O}^{''}$
- 3 Dimension excludes protrusion of screws or other convex part.





- Specifications unless any specific instructions are stated is at the standard magnification.
- •Specifications are subject to change without prior notice.

NikonRayfactVF 3.0x




Specifications

Model	L-OFM30093MN
Focal length	91.5mm
F Number (∞)	F4
NA (Diaphragm open)	0.094
Magnification scale	−3.0x
Reference wavelength	546.07nm(e-line)
Wavelength range	400∼700nm
Picture angle	13.0°
Image size	84mm ϕ
Object Size	28.0mm ϕ
Distortion	−0.06% ※1
Relative illumination	92.6% ※1
Aperture scale	4,5.6,8 (With a click stop ※2)
Object-to-image distance	481.7mm
Working distance	86.9mm
Mount size	M45(P=0.75)
Flange-to-image distance	335.6mm
Back focus	338.3mm
Attachment size	M40.5(P=0.5)
Diameter/length	51mm <i>φ</i> × 59.2mm ※3
Weight	Approximately 240g

- %1 Image size 84mm ϕ at F4
- X2 Diaphragm scale indicated with indexes.

No numeric indication. The open position index states as $\rm ^{\prime\prime}O^{\prime\prime}.$

3 Dimension excludes protrusion of screws or other convex part.



[•]Specifications unless any specific instructions are stated is at the standard magnification.

[•] Specifications are subject to change without prior notice.

For further queries, please contact; Marketing Sec. Industrial Equipment Dept. TOCHIGI NIKON COROPRATION

E-mail:ktn.eigyo@nikon.com TEL+81-287-28-7100 FAX+81-287-28-7170

Nikon Rayfact MJ Series


Features

- MJ90 : Variable magnification range of 0.05x 0.5x.
- MJ95 : Variable magnification of 0.5x 1.0x.
- Image size ϕ 82mm
- · High performance in all range of magnification.
- · Adjustable diaphragm, Diaphragm opening position at F4.
- · Aperture ring lockable screw and focus lockable screw for easy use.
- Unit sales with a wide range of mounts to fit in your camera.
- RoHS compliant.

- Image receiving process by both line and area censor cameras.
- Printed materials inspection.
- Fine pattern inspection e.g. PCB.
- Fine pattern inspection and detecting defects e.g. TAB, sheets.
- FPD inspection.

NikonRayfactMJ90mmF4





Specifications

Specifications					-	
Model		Refer to the following table				
Magnification range			−0.05x	~ −0.5x		
Magnification scale	-0.05x	−0.1x	−0.2x	−0.3x	-0.4x	−0.5x
Focal length	89.8mm	90.0mm	90.4mm	90.8mm	91.2mm	91.6mm
F Number (∞)			F	4		
NA (Diaphragm open)	0.006	0.011	0.021	0.029	0.036	0.042
Reference wavelength			546.07nr	m(e-line)		
Wavelength range			400∼	700nm		
Picture angle	47.2°	45.6°	42.3°	39.4°	36.7°	34.5°
Image size		82mm ϕ				
Object Size	1640.0mm	820.0mm	410.0mm	273.3mm	205.0mm	164.0mm
Distortion ※1	+0.47%	+0.31%	+0.14%	+0.06%	+0.05%	+0.07%
Relative illumination ※1	42.2%	45.0%	49.9%	54.0%	57.6%	60.7%
Aperture scale		4,5.6,8,11(V	Vith a diaphi	ragm lock, a	click stop)	
Object-to-image distance	1967.3mm	1069.6mm	634.2mm	496.3mm	432.3mm	397.7mm
Working distance	1820.4mm	922.6mm	487.2mm	348.0mm	274.4mm	230.3mm
Mount size		Refer to the following table				
Flange-to-image distance		Refer to the following table				
Back focus		Refer to the following table				
Attachment size		M52(P=0.75)				
Diameter/length		Refer to the following table				
Weight		R	efer to the 1	following tak	ole	

- X1 Highest image height (Y'=41mm) at F5.6
- $\frak{\%}2$ Diaphragm scales indicated with indexes. No numeric indication.

Model	Camera Mount	Diameter/length ※3	Weight
1) OVM05042MN-M72D1	M72(M.B.f=19.56mm)	84mm $\phi \times 131.3$ mm ~ 151.9 mm	Approximately 900g
2) OVM05042MN-M72D2	M72(M.B.f=6.56mm)	84mm ϕ × 144.3mm ~ 164.9mm	Approximately 930g
3) OVM05042MN-M72T	M72(M.B.f=28.8mm)	84mm ϕ × 122.2mm ~ 142.6mm	Approximately 880g
4) OVM05042MN-M72N	M72(M.B.f=31.8mm)	84mm $\phi \times 119.1$ mm ~ 139.7 mm	Approximately 870g
5) OVM05042MN-NMT	$M84.5 \times P0.5(M.B.f=41 mm)$	$93 \text{mm} \phi \times 110.4 \text{mm} \sim 130.9 \text{mm}$	Approximately 870g
6) OVM05042MN-FMT	F Mount (M.B.f=46.5mm)	84mm $\phi \times 104.9$ mm ~ 125.4 mm	Approximately 860g
7) OVM05042MN-VMT	V Mount Equivalency(M.B.f=15mm)	$100 \text{mm} \phi \times 141.9 \text{mm} \sim 162.5 \text{mm}$	Approximately 970g
8) OVM05042MN-BMT	Screw flange end(M.B.f=9mm)	102mm□ × 137.9mm ~ 158.4mm	Approximately 1020g
9) OVM05042MN-M95E	M95(M.B.f=9.4mm)	$100 \text{mm} \phi \times 137.5 \text{mm} \sim 158.0 \text{mm}$	Approximately 940g

 $\frak{3}$ Dimension excludes protrusion of screws or other convex part.

		-0.05x	−0.1x	−0.2x	−0.3x	−0.4x	−0.5x
Entrance Pupil	d	56.6mm	51.8mm	42.3mm	32.7mm	23.2mm	13.6mm
Littratice i upii	φ	22.2mm	22.2mm	22.2mm	22.2mm	22.3mm	22.3mm
Exit Pupil	d	−58.0mm	-63.0mm	-73.2mm	-83.4mm	-93.7mm	-104.0mm
Exit Pupil	φ	24.6mm	24.6mm	24.8mm	24.9mm	25.0mm	25.2mm
Front Principal Point [Fron	t.PP	64.5mm	60.0mm	51.0mm	41.9mm	32.9mm	23.9mm
Rear Principal Point [Rear.	PP]	-49.3mm	-54.1mm	-63.6mm	-73.2mm	-82.8mm	−92.4mm
Nodal point distance [HH']		11.9mm	12.2mm	12.7mm	13.2mm	13.8mm	14.4mm


- % Entrance pupil En.P and principal point H at the front tip point of the lens (ϕ 83mm).
- $\ensuremath{\ensuremath{\mathbb{X}}}$ Exit pupil $\,$ Ex.P, rear principal point H' at the mount side.

 $^{{}^{\:\}raisebox{3.5pt}{\textbf{.}}} {\text{Specifications unless any specific instructions are stated is at the standard magnification.}$

 $^{{\}mbox{\,{}^{\bullet}}} \mbox{Specifications}$ are subject to change without prior notice.

NikonRayfactMJ95mmF4





Specifications

Model		R	efer to the 1	ollowing tak	ole	
Magnification range		-0.5x ~ -1.0x				
Magnification scale	−0.5x	−0.6x	−0.7x	−0.8x	−0.9x	-1.0x
Focal length	93.9mm	94.3mm	94.7mm	95.1mm	95.5mm	95.9mm
F Number (∞)			F	4		
NA (Diaphragm open)	0.041	0.047	0.051	0.055	0.059	0.062
Reference wavelength			546.07nr	n(e-line)		
Wavelength range				700nm		
Picture angle	33.5°	31.6°	29.9°	28.4°	27.0°	25.7°
Image size		82mm ϕ				
Object Size	164.0mm	136.7mm	117.1mm	102.5mm	91.1mm	82.0mm
Distortion 💥1	-0.20%	-0.15%	-0.10%	-0.04%	+0.02%	+0.08%
Relative illumination ※1	61.9%	64.7%	67.5%	69.9%	72.0%	73.9%
Aperture scale		4,5.6,8,11(V	Vith a diaphi	ragm lock, a	click stop)	
Object-to-image distance	408.0mm	386.6mm	374.5mm	368.1mm	365.4mm	365.3mm
Working distance	199.3mm	177.9mm	165.8mm	159.4mm	152.0mm	141.8mm
Mount size	Refer to the following table					
Flange-to-image distance	Refer to the following table					
Back focus		Refer to the following table				
Attachment size		M52(P=0.75)				
Diameter/length		Refer to the following table				
Weight		R	efer to the f	following tak	ole	

- ※1 Highest image height (Y'=41mm) at F5.6.
- $\divideontimes 2$ Diaphragm scales indicated with indexes. No numeric indication.

Model	Camera Mount	Diameter/length ※3	Weight
1) OVM10062MN-1-M72D1	M72(M.B.f=19.56mm)	84mm ϕ × 193.1mm ~ 208.0mm	Approximately 1230g
2) OVM10062MN-1-M72D2	M72(M.B.f=6.56mm)	84mm $\phi \times 206.1$ mm \sim 221.0mm	Approximately 1260g
3) OVM10062MN-1-M72T	M72(M.B.f=28.8mm)	84mm $\phi \times 180.9$ mm ~ 195.8 mm	Approximately 1210g
4) OVM10062MN-1-M72N	M72(M.B.f=31.8mm)	84mm $\phi \times 180.9$ mm ~ 195.7 mm	Approximately 1200g
5) OVM10062MN-1-NMT	$M84.5 \times P0.5(M.B.f=41mm)$	84mm $\phi \times 172.2$ mm ~ 187.1 mm	Approximately 1200g
6) OVM10062MN-1-VMT	V Mount Equivalency(M.B.f=15mm)	$100 \text{mm} \phi \times 203.7 \text{mm} \sim 218.6 \text{mm}$	Approximately 1300g
7) OVM10062MN-1-BMT	Screw flange end(M.B.f=9mm)	102mm□ × 199.7mm ~ 214.6mm	Approximately 1350g
8) OVM10062MN-1-M95E	M95(M.B.f=9.4mm)	$100 \text{mm} \phi \times 193.3 \text{mm} \sim 214.2 \text{mm}$	Approximately 1270g

X3 Dimension excludes protrusion of screws or other convex part.

	−0.5x	−0.6x	−0.7x	−0.8x	−0.9x	−1.0x
d	73.5mm	63.4mm	53.3mm	43.2mm	33.1mm	23.0mm
φ	22.5mm	22.5mm	22.5mm	22.4mm	22.4mm	22.3mm
d	-106.4mm	-117.2mm	-128.0mm	-138.8mm	-149.7mm	-160.6mm
φ	25.2mm	25.3mm	25.4mm	25.4mm	25.5mm	25.6mm
PΡ	83.1mm	73.5mm	63.9mm	54.3mm	44.7mm	35.1mm
P]	−95.7mm	-105.8mm	-116.1mm	-126.3mm	-136.5mm	-146.8mm
	15.1mm	15.6mm	16.2mm	16.9mm	17.5mm	18.2mm
	φ d φ PP	 φ 22.5mm d -106.4mm φ 25.2mm PP 83.1mm P] -95.7mm 	$ \begin{array}{c ccccc} \phi & 22.5 \text{mm} & 22.5 \text{mm} \\ \text{d} & -106.4 \text{mm} & -117.2 \text{mm} \\ \phi & 25.2 \text{mm} & 25.3 \text{mm} \\ \text{PP} & 83.1 \text{mm} & 73.5 \text{mm} \\ \text{P]} & -95.7 \text{mm} & -105.8 \text{mm} \end{array} $	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$

- \divideontimes Entrance pupil En.P and principal point H at the front tip point of the lens (ϕ 83mm).
- X Exit pupil Ex.P, rear principal point H' at the mount side.
- X Image side : [+], Object side : [-]

 $^{{}^{\}scriptscriptstyle \bullet}\mathsf{Specifications}$ are subject to change without prior notice.

For further queries, please contact ; Marketing Sec. Industrial Equipment Dept.
TOCHIGI NIKON CORPORATION

E-mail:ktn.eigyo@nikon.com TEL+81-287-28-7100 FAX+81-287-28-7170

Nikon Rayfact GF Series

Features

- Lens mount : F mount for your use of various CCD cameras.
- High resolution and uniformity from the center to the edge of the lens.
- Minimal distortion (0.1% at the standard magnification).
- · Aperture ring lockable screw and focus lockable screw for easy to use.
- · RoHS compliant.

- For high resolution cameras (CCD pixel size : 4.7 μ m)
- FPD inspection.
- Fine pattern inspection e.g. PCB.
- \bullet Fine pattern inspection and detecting defects e.g. TAB, sheets.
- Printed materials inspection.







Model	QVM0235023MF
Focal length	80.8mm
F Number (∞)	F4
NA (Diaphragm open)	0.024
Magnification scale	−0.235x
Magnification range	-0.188x ~ -0.313x
Reference wavelength	546.07nm(e-line)
Wavelength range	400∼700nm
Picture angle	21.1°
Image size	36mm ϕ
Object Size	153.2mm <i>φ</i> ※ 1
Distortion	−0.06% ※ 1
Relative illumination	86.2% ※1
Aperture scale	4,5.6,8(With a diaphragm lock, a click stop)
Object-to-image distance	507.7mm ※1
Working distance	383.6mm ※1
Mount size	F Mount
Flange-to-image distance	46.5mm
Back focus	66.8mm
Attachment size	M30.5(P=0.5)
Diameter/length	65mm
Weight	Approximately 350g

- ※1 Value at the standard magnification.
- $\frak{\%}2$ Dimension excludes protrusion of screws or other convex part.

Model	QVM05041MF
Focal length	81.9mm
F Number (∞)	F4
NA (Diaphragm open)	0.04
Magnification scale	−0.47x
Magnification range	-0.4x ~ -0.5x
Reference wavelength	546.07nm(e-line)
Wavelength range	400∼700nm
Picture angle	17.8°
Image size	36mm ϕ
Object Size	76.6mm <i>φ</i> ※ 1
Distortion	−0.09% ※ 1
Relative illumination	94.0% ※1
Aperture scale	4,5.6,8(With a diaphragm lock, a click stop)
Object-to-image distance	360.4mm ※1
Working distance	217.6mm ※1
Mount size	F Mount
Flange-to-image distance	46.5mm
Back focus	85.5mm
Attachment size	M30.5(P=0.5)
Diameter/length	63.4mm $\phi \times 100.8$ mm $\%2$
Weight	Approximately 440g
×1 Value at the standard	I magnification

- X1 Value at the standard magnification.
- $\ensuremath{\aleph}2$ Dimension excludes protrusion of screws or other convex part.





- •Specifications unless any specific instructions are stated is at the standard magnification.
- •Specifications are subject to change without prior notice.







QVM07052MF
82.7mm
F4
0.051
−0.7x
-0.65x ~ -0.75x
546.07nm(e-line)
400∼700nm
14.6°
36mm ϕ
φ51.4mm ※1
−0.08% ※ 1
92.6% ※1
4,5.6,8(With a diaphragm lock, a click stop)
323.3mm ※1
160.5mm ※1
F Mount
46.5mm
104.3mm
M30.5(P=0.5)
65mm
Approximately 460g

- ※1 Data at the standard magnification.
- $\divideontimes 2$ Dimension excludes protrusion of screws or other convex part.

Model	QVM10065MF
Focal length	83.3mm
F Number (∞)	F4
NA (Diaphragm open)	0.063
Magnification scale	−1.0x
Magnification range	-0.95x ~ -1.05x
Reference wavelength	546.07nm (e-line)
Wavelength range	400∼700nm
Picture angle	12.8°
Image size	36mm ϕ
Object Size	φ36mm ※1
Distortion	−0.06% ※ 1
Relative illumination	90.7% ※1
Aperture scale	4,5.6,8(With a diaphragm lock, a click stop)
Object-to-image distance	313.1mm ※1
Working distance	124.8mm ※1
Mount size	F Mount
Flange-to-image distance	46.5mm
Back focus	129.5mm
Attachment size	M30.5(P=0.5)
Diameter/length	63.4mm ϕ × 146.9mm $\%$ 2
Weight	Approximately 490g
W1 Data at the standard	magnification

- X1 Data at the standard magnification.
- $\divideontimes 2$ Dimension excludes protrusion of screws or other convex part.





 $^{{}^{}ullet}$ Specifications unless any specific instructions are stated is at the standard magnification.

[•] Specifications are subject to change without prior notice.

For further queries, please contact;
Marketing Sec. Industrial Equipment Dept.
TOCHIGI NIKON CORPORATION
E-mail:ktn.eigyo@nikon.com
TEL+81-287-28-7100 FAX+81-287-28-7170

Nikon Rayfact IL Series

Features

- · Compatible with EL·Nikkor40mmF4N, 50mmF2.8N, 63mmF2.8N and 75mmF4N
- Lineup: 4 models
- •New product release : \[\text{NikonRayfactIL95mmF5.6N} \]
 - * 4 models cover a wide range of magnification (0.25x ~ 2.0x)
 - * Image size ϕ 90mm (The largest image size in our standard models)
- Minimal chromatic aberration in the range of 380nm 700nm.
- · Aperture ring lockable screw for easy use.
- · RoHS compliant.

- CCD camera photographing. (Both line and area sensor cameras)
- · Printed materials inspection.
- Fine pattern inspection e.g. PCB.
- Fine pattern inspection and detecting defects e.g. TAB, sheets.


NikonRavfactIL50mmF2.8N



Specifications

Specifications	
Model	PF4040ML
Focal length	40.1mm
F Number (∞)	F4
NA (Diaphragm open)	0.011
Magnification scale	−0.1x
Magnification range	-0.033x ~ -0.2x
Reference wavelength	587.56nm(d-line)
Wavelength range	380∼700nm
Picture angle	52.2° ※1
Image size	43.2mm ϕ
Object Size	432.0mm <i>φ</i> ※1
Distortion	−0.27% ※ 1
Relative illumination	55.3%
Aperture scale	4,5.6,8,11,16,22(1/2 dials with a finger stop)
Object-to-image distance	493.7mm ※1
Working distance	419.5mm ※1
Mount size	d=39mm 1/P=26(Leica)
Flange-to-image distance	47.0mm <u>※</u> 1
Back focus	33.0mm <u>※</u> 1
Attachment size	M40.5(P=0.5)
Diameter/length	$51.2 \text{mm} \phi \times 42 \text{mm} \times 2$
Weight	Approximately 125g


- imes1 Data : Magnification 0.1x, F4, ϕ 43.2mm
- X2 Dimension excludes protrusion of screws or other convex parts.





Model	PFM0125020ML
Focal length	52.1mm
F Number (∞)	F2.8
NA (Diaphragm open)	0.02
Magnification scale	−0.125x
Magnification range	-0.05x ~ -0.5x
Reference wavelength	587.56nm (d-line)
Wavelength range	380∼700nm
Picture angle	41°
Image size	43.2mm ϕ
Object Size	345.6mm ϕ $\%$ 1
Distortion	−0.48% ※1
Relative illumination	47.7% ※1
Aperture scale	2.8,4,5.6,8,11,16 (With a finger stop ※2)
Object-to-image distance	513.3mm <u>※</u> 1
Working distance	437.0mm ※ 1
Mount size	d=39mm 1/P=26(Leica)
Flange-to-image distance	49.1mm <u>※</u> 1
Back focus	37.7mm <u>※</u> 1
Attachment size	M40.5(P=0.5)
Diameter/length	51 mm $\phi \times 39.8$ mm $\%2$
Weight	Approximately 135g
V/4 D : 14 'C :' (105 500 1100

- 31 Data: Magnification 0.125x, F2.8, ϕ 43.2mm
- X2 Dimension excludes protrusion of screws or other convex parts.
- *3 Diaphragm shows by index only no numerical indication.



- $\bullet \text{Specifications unless any specific instructions are stated is at the standard magnification}. \\$
- $\mbox{\,{}^{\bullet}\hspace{-1pt}}\mbox{Specifications}$ are subject to change without prior notice.


NikonRavfactIL75mmF4N





Specifications	
Model	OFM0125020ML
Focal length	63.0mm
F Number (∞)	F2.8
NA (Diaphragm open)	0.02
Magnification scale	−0.125x
Magnification range	-0.05x ~ -0.5x
Reference wavelength	587.56nm(d-line)
Wavelength range	380∼700nm
Picture angle	44.4° ※1
Image size	58mm ϕ
Object Size	464mm ϕ $lpha$ 1
Distortion	+0.12% ※1
Relative illumination	39.3%
Aperture scale	$2.8,4,5.6,8,11,16$ (With a finger stop $\times 2$)
Object-to-image distance	632.8mm ※1
Working distance	542.8mm ※1
Mount size	d=39mm 1/P=26(Leica)
Flange-to-image distance	62.8mm ※1
Back focus	48.2mm ※1
Attachment size	M40.5(P=0.5)
Diameter/length	51mm
Weight	Approximately 150g


- imes1 Data : Magnification 0.125x, F2.8, ϕ 58mm
- X2 Dimension excludes protrusion of screws or other convex part.
- X3 Diaphragm shows by index only no numerical indication. (Diaphragm opening index indicated)





Model	OFM0200020ML
Focal length	75.2mm
F Number (∞)	F4
NA (Diaphragm open)	0.021
Magnification scale	−0.2x
Magnification range	-0.1x ~ -0.5x
Reference wavelength	587.56nm (d-line)
Wavelength range	380∼700nm
Picture angle	47.81° ※1
Image size	80mm ϕ
Object Size	400.0 mm $\phi imes 1$
Distortion	-0.04% ※1
Relative illumination	30.2% ※1
Aperture scale	4,5.6,8,11,16,22(With a finger stop 💥2)
Object-to-image distance	544.1mm ※1
Working distance	436.8mm ※1
Mount size	d=39mm 1/P=26(Leica)
Flange-to-image distance	80.1mm <u>※</u> 1
Back focus	76.5mm <u>※</u> 1
Attachment size	M40.5(P=0.5)
Diameter/length	51 mm $\phi \times 35$ mm $\%2$
Weight	Approximately 120g

- \divideontimes 1 Data : Magnification 0.2x, F4, ϕ 80mm
- $\frak{\%}2$ Dimension excludes protrusion of screws or other convex part.
- ※3 Diaphragm shows by index only no numerical indication. (Diaphragm opening index indicated)



- *Specifications unless any specific instructions are stated is at the standard magnification.
- $\mbox{\,{}^{\bullet}\hspace{-1pt}}\mbox{Specifications}$ are subject to change without prior notice.

NikonRayfactIL63mm(F)






Model: OFM0125020MF-B

Model: OFM0125020MF-T


Specifications

wF-T «) 3x						
3×						
3x						
_						
mm ϕ						
stop)						
m ※1						
imately 295g						

💥 1 Dimension excludes protrusion of screws or other convex part. $(\mathsf{OFM0125020MF-B}\text{--}0.07x} \ \ \mathsf{OFM0125020MF-T}\text{--}0.2x)$



Model:OFM0125020MF-B



Model: OFM0125020MF-T

 $^{\ \, \}hbox{`Specifications unless any specific instructions are stated is at the standard magnification.}$

[•] Specifications are subject to change without prior notice.

NikonRayfactIL95mmF5.6N



Specifications


OFM0300020ML	OFM0600033ML	OFM1000044ML	OFM0600033ML							
-0.25x ~ -0.5x	-0.5x ~ -0.75x	-0.75x ~ -1.25x	-1.25x ~ -2.0x							
−0.3x	−0.6x	-1.0x	−1.66x							
95.1mm	95.6mm	95.6mm	95.6mm							
	F5	5.6								
0.021	0.033	0.056								
	587.56nn									
	380nm∼700nm									
40.2°	32.8°	26.4°	20.0°							
	90.0n	nm ϕ								
300mm ϕ	150mm ϕ	90.0mm ϕ	54.0mm ϕ							
-0.11%	+0.08%	0.00%	-0.03%							
54.2%	69.9%	81.27%	91.4%							
Index (no nume	l l									
531.0mm	402.9mm	377.4mm	402.9mm							
381.4mm	255.7mm	161.9mm	125.6mm							
d	=39mm 1/P=26(Leica)	M43(P=0.75)							
117.3mm	144.8mm	183.2mm	225.7mm							
	M43(P	=0.75)								
51.0 mm $\phi \times 51.6$ mm	$51.0 \text{mm} \phi \times 51.55 \text{mm}$	51.0 mm $\phi \times 51.4$ mm	$51.0 \text{mm} \phi \times 51.55 \text{mm}$							
Approximately 120g	Approximately 120g	Approximately 120g								
	$-0.25x \sim -0.5x$ $-0.3x$ $95.1mm$ 0.021 40.2° $300mm \phi$ -0.11% 54.2% Index (no nume 531.0mm $381.4mm$ $117.3mm$	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$							


- ※1 Data: Standard magnification -0.3x, -0.6x, -1.0x, -1.66x F5.6, φ90mm
- *2 Diaphragm shows by index only no numerical indication.


(Diaphragm open index indicated)

 $\slash\hspace{-0.8em}\cancel{\times}3$ Magnification –1.66x : To use –0.6x lens at the reverse side.

Lens mount \rightarrow To use the filter attachment (magnification at -0.6x).







OFM0300020ML OFM0600033ML OFM1000044ML

 $^{\, \}cdot \, \text{Specifications} \,$ unless any specific instructions are stated is at the standard magnification.

[•]Specifications are subject to change without prior notice.

For further queries, please contact;
Marketing Sec. Industrial Equipment Dept.
TOCHIGI NIKON CORPORATION

E-mail:ktn.eigyo@nikon.com TEL+81-287-28-7100 FAX+81-287-28-7170

UV105mm-F4.5

Features

- For photographing in the ultraviolet light range.
- No focus correction required at the time of photographing UV when you focus under visible light.
 High transmittance rate (approx. 70%) in the wide range of high wavelength 220nm 900nm. Minimal distortion at the magnification ∞ – 0.5x.
- RoHS compliant.

- Combustion study
- Plasma study
- · Electric discharge study


UV105mm-F4.5



Specifications

Model	PF10545MF-UV
Focal length	105.2mm
F Number (∞)	F4.5
NA (Diaphragm open)	0.037
Magnification scale	-
Magnification range	∞~-0.5x
Reference wavelength	546.07nm(e-line)
Wavelength range	220~900nm
Picture angle	23.3°
Image size	43.6mm ϕ
Object Size	87.2mm <i>φ</i> (−0.5x)
Distortion	-0.25~-0.07%
Relative illumination X1	51.4%
Aperture scale	4.5,5.6,8,11,16,22,32
Object-to-image distance	∞~481.2mm
Working distance	∞~273.9mm
Mount size	F Mount
Flange-to-image distance	46.5mm
Back focus	87.1~139.7mm
Attachment size	M52(P=0.75)
Diameter/length	68.5mm <i>φ</i> × 116.5mm ※2
Weight	Approximately 515g

- ※1 Data: Magnification at 0.5x
- X1 Data: Magnification at 0.0xX2 108mm from the mount surface.



- ${}^{\bullet} \text{Specifications unless any specific instructions are stated is at the standard magnification}. \\$
- Specifications are subject to change without prior notice.

For further queries, please contact;
Marketing Sec. Industrial Equipment Dept.
TOCHIGI NIKON CORPORATION
E-mail:ktn.eigyo@nikon.com
TEL+81-287-28-7100 FAX+81-287-28-7170

Marketing Sec. Industrial Equipment Dept.

Underlined product : Build-to-order product

♦ Customized products available

Note	_	Underlined product : Build-to-orde	r product														Separate cale:												
Noon Reprint 1756			Magnification range													I	mage si	ize [mi	m]		Separate sale: Camera mount (order product)※3								
Nison Rayfact 12-5x (prime mahala.metals)	$ \ \ $	Product name	Model	<0.05 0.1	1 0.1	~	0.5	0.7	1.0	1.4	~	2.0	~	3.5	5.0	7.0	<36	36	43.2	58	62	>08			M72	M72	M72	M72	
Nikon Rayfact 17x (Consigle title Type)		Nikon Rayfact 2-5x	L-OVM50167MN									•			•							•		\Q	♦	\Q	\Q	\Q	\Q
Nikon Rayfact 7x (Epi distribution topo)		Nikon Rayfact 2-5x (prism suitable model)	L-OVM50170MN-BS									+			•							•		\Q	♦	\Q	♦	\Q	\Q
Nikon Raylact 235c		Nikon Rayfact 7x (Straight tube type)	OFM70350HN-TS													•					•					•			
Nikon Raylact 235c	on Rayfact	Nikon Rayfact 7x (Epi-illumination type)	OFM70350HN-TP													•					•					•			
Nikon Raylact 235c		Nikon Rayfact 3.5x (※1)	OFM35162MN											•							•			•	•	•	♦	•	
Nikon Rayfact 17.5x		Nikon Rayfact 2.35x	OFM24125MN										•								•			•	•	•	\Q	•	
Nikon Rayfact 1x	ž	Nikon Rayfact 2x	OFM20119MN									•									•			•	•	•	\Q	•	
Nikon Rayfact V1.0.5x		Nikon Rayfact 1.75x	L-OFM18113MN								•										•			•	•	•	\Q	•	
Nikon Rayfact VL0.5x		Nikon Rayfact 1x	OFM10090MN						•												•			•	•	•	\Q	•	
Nikon Rayfact VL0.7x		Nikon Rayfact 0.5x (※2)	OFM20119MN				•										•							•	•	•	♦	•	
Nikon Rayfact VL1.0x		Nikon Rayfact VL0.5x	L-OFM05034MN				•														•			•	•	•	♦	•	
Nikon Rayfact VU.1.0x		Nikon Rayfact VL0.7x	L-OFM07042MN					•													•			•	•	•	\Q	•	
Nikon Rayfact VW0.14x	>	Nikon Rayfact VL1.0x	L-OFM10051MN						•												•			•	•	•	\Q	•	
Nikon Rayfact VW0.25x		Nikon Rayfact VL1.4x	L-OFM14060MN							•											•			•	•	•	♦	•	
Nikon Rayfact VW0.35x		Nikon Rayfact VW0.14x	L-OFM014012MN		*	•															•			•	•	•	\Q	•	
Nikon Rayfact VF L-OVM30093MN	*	Nikon Rayfact VW0.25x	L-OFM025020MN			•															•			•	•	•	\Q	•	
Nikon Rayfact VF 1x		Nikon Rayfact VW0.35x	L-OFM035026MN			•															•			•	•	•	\Q	•	
Nikon Rayfact VF 1.4x (Fixed)	11	Nikon Rayfact VF	L-OVM30093MN				+						•												•	•	♦	•	
Nikon Rayfact VF 2x (Fixed)		Nikon Rayfact VF 1x (Fixed)	L-OFM10062MN						•												•				•	•	\Diamond	•	
Nikon Rayfact VF 2x (Fixed)		Nikon Rayfact VF 1.4x (Fixed)	L-OFM14073MN							•											•				•	•	\Diamond	•	
Nikon Rayfact VF 3x	>	Nikon Rayfact VF 2x (Fixed)	L-OFM20083MN									•										•			•	•	\Diamond	•	
Nikon Rayfact 80mmF4 (0.235x) QVM0235023MF →		Nikon Rayfact VF 2.5x (Fixed)	L-OFM25089MN										•									•			•	•	\Diamond	•	
Nikon Rayfact 80mmF4 (0.47x)		Nikon Rayfact VF 3x (Fixed)	L-OFM30093MN										•									•			•	•	\Diamond	•	
Nikon Rayfact 80mmF4 (0.7x) QVM07052MF		Nikon Rayfact 80mmF4(0.235x)	QVM0235023MF			+												•						•					
Nikon Rayfact 80mmF4 (0.7x) QVM07052MF ★	ш	Nikon Rayfact 80mmF4(0.47x)	QVM05041MF				-											•						•					
Nikon Rayfact IL40mm	g	Nikon Rayfact 80mmF4 (0.7x)	QVM07052MF					•										•						•					
Nikon Rayfact IL50mmF2.8N PFM0125020ML ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑		Nikon Rayfact 80mmF4 (1.0x)	QVM10065MF						+									•						•					
Nikon Rayfact IL63mmF2.8N		Nikon Rayfact IL40mm	PF4040ML	•		•													•										•
L Nikon Rayfact IL63mmF2.8N(F) OFM0125020MF-B →	1	Nikon Rayfact IL50mmF2.8N	PFM0125020ML	•	+		•												•										•
Image: Light of the properties of the prop		Nikon Rayfact IL63mmF2.8N	OFM0125020ML	•			•													•									•
Nikon Rayfact IL75mmF4N		L Nikon Rayfact IL63mmF2.8N(F)	OFM0125020MF-B			*													•					•					
Nikon Rayfact IL75mmF4N OFM020020ML ◆		L Nikon Rayfact IL63mmF2.8N(F)	OFM0125020MF-T	•	+	•													•					•					
		Nikon Rayfact IL75mmF4N	OFM0200020ML		•		•															•							•
AND DICTION OF SECOND OF MOREOGRAPHICAL AND		Nikon Rayfact IL95mmF5.6N	OFM0300020ML			•	•															•		•	•	•	•	•	•
NIKON RAYTACT ILEEDMMT-3.0N OF-MUDUUUU33ML		Nikon Rayfact IL95mmF5.6N	OFM0600033ML				•	•														•		•	•	•	•	•	•
Nikon Rayfact IL95mmF5.6N OFM1000044ML ◆		Nikon Rayfact IL95mmF5.6N	OFM1000044ML					•		•												•		•	•	•	•	•	•
Nikon Rayfact IL95mmF5.6N (※5)		Nikon Rayfact IL95mmF5.6N (%5)	OFM0600033ML	$\sqcup \bot$						•		•										•		•	•	•	•	•	•
Nikon Rayfact MJ90mmF4	l)	Nikon Rayfact MJ90mmF4	OVM05042MN	•	+		•															•		•	•	•	•	•	•
S Nikon Rayfact MJ95mmF4 OVM10062MN-1 ◆	2	Nikon Rayfact MJ95mmF4	OVM10062MN-1				•		•													•			•	•	•	•	•

^(%1) Option item : Coaxial epi-illumination tube

(%3) RF7x (both straight tube type and epi-illumination type) •GF•IL63(F) and MJ to be sold with a camera mount attached on it.

^(%2) To use Nikon Rayfact 2x at the reversed direction at the magnification of 0.5x

⁽¾4) NikonRayfactVF fixed magnification models : Customized magnification types are available.

^(%5) To use IL95mmF5.6N (OFM0600033ML) at the reversed direction at the magnification of 0.6x.